

CLEANING INSTRUCTIONS

LEXAN™ POLYCARBONATE SHEETS



SABIC offers a high-performance, engineering thermoplastics LEXAN™ sheet and film portfolio and full-service solutions for customers in various segments, including mass transportation, consumer electronics, glazing, building and construction.

The company supports customers by providing materials that comply with relevant regulations, enabling customers to find new solutions to evolving requirements for fire safety, as well as related challenges of sustainability and cost reduction.

SABIC's LEXAN sheet products are directly extruded from LEXAN™ resin and offer significant advantages over many other glazing materials in terms of design freedom, light-weight, fire performance, UV protection and thermal insulation.

Furthermore, LEXAN sheet combines high impact resistance with optical clarity, thus providing superior safety and security against vandalism and intrusion.

Periodic cleaning of LEXAN polycarbonate sheet, using correct procedures with compatible household cleaners, is recommended to prolong the service life of your material. In the following pages you can read and learn how to clean LEXAN sheets in the best ways and to keep them in good condition.





These cleaning recommendations apply to all LEXAN™ polycarbonate sheet products, including, but not limited to, LEXAN solid sheet and signs, LEXAN coated MARGARD™ sheet and LEXAN™ THERMOCLEAR™ (multiwall) sheet. These techniques are based on standard industry practices.

CLEANING PROCEDURE FOR SMALL AREAS MANUAL:

- 1** Gently wash the sheet with a solution of mild soap and lukewarm water, using a soft, grid free cloth or sponge to loosen any dirt or grime.
- 2** Fresh paint splashes, grease and smeared glazing compounds can be removed easily before drying by rubbing lightly with a soft cloth using petroleum ether (BP65), hexane or heptane. Afterwards, wash the sheet using mild soap and lukewarm water.
- 3** Scratches and minor abrasions can be minimized by using a mild automobile polish. We suggest that a test be made on a small area of LEXAN sheet with the polish selected and that the polish manufacturer's instructions be followed, prior to using the polish on the entire sheet.
- 4** Finally, thoroughly rinse with clean water to remove any cleaner residue and dry the surface with a soft cloth to prevent water spotting.

CLEANING PROCEDURE FOR LARGE AREAS AUTOMATED:

- 1** Clean the surface using a high pressure water cleaner (max. 100bar or 1,450psi) and/or a steam cleaner. We suggest that a test be made on a small area, prior to cleaning the entire sheet.
- 2** Use of additives to the water and/or steam should be avoided.



OTHER IMPORTANT INSTRUCTIONS FOR ALL LEXAN SHEETS:

- Never use abrasive or highly alkaline cleaner on LEXAN polycarbonate materials.
- Never use aromatic or halogenated solvents like toluene, benzene, gasoline, acetone or carbon tetrachloride on LEXAN polycarbonate materials.
- Use of incompatible cleaning materials with LEXAN sheet can cause structural and/or surface damage. Please contact your SABIC representative in case of any doubts of your cleaning material.
- Contact with harsh solvents such as methyl ethyl ketone (MEK) or hydrochloric acid can result in surface degradation and possible crazing of LEXAN sheet.
- Never scrub with brushes, steel wool or other abrasive materials.
- Never use squeegees, razorblades or other sharp instruments to remove deposits or spots.
- Do not clean LEXAN polycarbonate sheet in direct sunlight or at high temperatures as this can lead to staining.
- For all mentioned chemicals consult the manufacturer's material safety datasheet (MSDS) for proper safety.



ADDITIONAL IMPORTANT CONSIDERATIONS FOR MULTIWALL AND CORRUGATED SHEET:

- Cleaners and solvents generally recommended for use on polycarbonate are not necessarily compatible with the UV protected surfaces of LEXAN multiwall, corrugated and sign polycarbonate sheet materials.
- Do not use alcohols on the UV protected surfaces of LEXAN sheet.
- Never clean the DRIPGARD surface of LEXAN multiwall sheet and corrugated sheets.



GRAFFITI REMOVAL FROM LEXAN™ MARGARD™ SHEET

- Use butyl cellosolve with a clean, soft cloth to remove paints, marking pen inks and lipstick. Afterwards wash the sheet using mild soap and lukewarm water, then rinse with clean water to remove residue and dry with a soft cloth.
- Masking tape and adhesive tape work well for lifting off old, weathered paints.
- To remove label stickers, the use of kerosene or petroleum ether (BP65) is generally effective. If the solvent does not penetrate the sticker material, apply heat (hair dryer) to soften the adhesive and promote removal of the sticker. Afterwards the cleaning procedure for small areas as outlined in the previous page should be followed.





CHEMICAL COMPATIBILITY OVERVIEW

This overview shows the chemical resistancy of LEXAN™ uncoated polycarbonate sheet. Chemical compatibility of thermoplastics e.g. LEXAN™ sheet is dependent on contact time, temperature and stress (external stress to which the application is subjected). Chemical exposure can result in discoloration, softening, swelling, crazing, cracking or loss of properties of the thermoplastic. The chemicals listed have been evaluated for LEXAN™ sheet according a very stringent SABIC-test method.

This test incorporates exposure to the chemical under defined conditions including temperature (20 and 80°C) and stress (0.5 and 1% strain) for a time period of seven days. The results are listed in the overview using symbols (+ or 0 or -) which are explained below.

This information should be used as indicative only. The true chemical compatibility can only be determined under conditions as in the final application. Please contact your local representative in case additional information is required, for example related to coated polycarbonate sheet solutions.

- Poor	Not recommended-will result in failure or severe degradation.
0 Fair	Found marginal-only for short exposures at lower temperatures or when loss of properties is not critical.
+ Good	Found unaffected in its performance when exposed with regards to time, temperature and stress according the SABIC-test method.

Acid, Mineral

Borax acid	+
Hydrogen chloride 20%	+
Hydrogen chloride 25%	-
Hydrogen fluoride 25%	+
Nitric acid 70%	-
Perchloric acid	-
Phosphorus pentoxide dry	+
Phosphoric acid 1%	+
Phosphoric acid 10%	-
Phosphorus pentachloride	+
Sulfuric acid 50%	+
Sulfuric acid 70%	-
Sulfurous acid 5%	-

Acid, Organic

Acetic anhydride	-
Formic acid concentrate	-
Gallic acid	+
Maleic acid	+
Mercapto acetic acid	-
Muristic acid 20%	+
Muristic acid 25%	-
Oleic acid	+
Palmitic acid	+
Phenol sulfonic acid	-
Phenoxyacetic acid	+
Phthalic anhydride	+
Salicylate acid	+
Tannic acid	+
Tannic acid 20%	-
Thiodiacetic acid	+
Trichlor acetic acid 10%	-
5% Sulfamine acid	0

Alcohol

Allyl alcohol	-
Amyl alcohol	-
Butoxyethanol	-
Chlorethanol 2	-
Decyl alcohol	-
Dodecyl alcohol	-
Ethanol	-
Ethyl glycol 100%	-
Ethyl glycol 60%	+
Furfuryl alcohol	-
Glycerine	+
Hepthyl alcohol	-
Isobutanol	0
Nonyl alcohol	-
Octyl alcohol	+
Oxydiethanol 2.2	+
Phenethyl alcohol	-
Polyalkylene glycol	-
Polyethylene glycol	+
Propylene glycol	-
Sorbitol	+
Thiodiglycol 5%	-
Triethylene glycol	+
Tripropylene glycol	-
Phenoxyacetic	+
Phenol sulfonic acid	-
Phenol 5%	-
Aluminium ammonium sulfate	-
Aluminium chloride	-
Aluminium fluoride	+
Aluminium potassium sulfate	-
Aluminium sodium sulfate	+
Ammonium bicarbonate	+

Alcohol (cont.)

Ammonium bromide	+
Ammonium carbonate	-
Ammonium dichromate	+
Ammonium persulfate	+
Arsenic trioxide	-
Barium carbonate	+
Barium chloride	+
Barium sulfate	+
Calcium carbonate paste	-
Calcium chloride	+
Calcium sulfate	+
Cesium bromide	+
Copper (II) chloride 5%	+
Iron (II) chloride	-
Iron (III) ammonium sulfate	+
Iron (III) chloride saturated	+
Iron (III) nitrate	-
Iron (III) sulfate	+
Lithium bromide	+
Lithium hydride powder	+
Magnesium bromide	+

Aldehyde

Acetaldehyde	-
Butyraldehyde	-
Formaldehyde solvent 37%	+
Formalin	+
Propionaldehyde	-

Amide

Dimethylformamide	-
-------------------	---

Amine

Aniline	-
Diphenylamine	-
Methylaniline N	-
Methylene dianiline	-
Phenylhydrazine	-
Pyridine	-
Triethanolamine	+
Hydroxylamine	+

Base

Aluminium hydroxide powder	+
Ammonia concentrate	-
Ammonium hydroxide 0.13%	-
Calcium hydroxide	-
Potassium hydroxide 10%	-
Sodium hydroxide dry	+
Sodium hydroxide 10%	-
Sodium thotalamate	+

Ester

Benzyl benzoate	-
Butyl cellosolve acetate	-
Butyl stearate	-
Cello acetobutyrate	-
Cellulose acetate	-
Cellulose propionate	-
Dibutyl phthalate	-
Didecyl carbonate	-
Diisodecyl phthalate	-
Diisononyl phthalate	+
Dioctyl phthalate	-
Dioctyl sebacate	-
Ditridecyl carbonate	-
Ditridecyl phthalate	-
Ethyl bromoacetate	+
Ethyl butyrate	-
Ethyl cellusolve 5%	-
Ethyl chloracetate	-
Ethyl cyanoacetate	-
Ethyl lactate	-
Ethyl salicylate	-
Isopropyl myristate	-
Methyl acetate	+
Methyl salicylate	-
Methylbenzoate	-
Triacetine	-
Magnesium sulfate	+
Magnesium chloride	+
Magnesium nitrate	+
Natriumetherlaurylsulfate	0
Nickel nitrate	+
Potassium bicarbonate dry	+
Potassium bisulfate	+
Potassium bromate	+
Potassium bromide	+
Potassium carbonate	+
Potassium chlorate	+
Potassium chloride saturated	-

Ester (cont.)

Potassium chloride 15%	+
Potassium chormium sulfate	-
Potassium cyanide powder	+
Potassium dichromate	+
Potassium iodide	+
Potassium nitrate	+
Potassium permanganate	-
Potassium persulfate	+
Potassium sulfate	+
Silver chloride saturated	-
Silver nitrate	+
Sodium bicarbonate saturated	0
Sodium bicarbonate 13%	-
Sodium bisulfate	+
Sodium bromate	+
Sodium bromide	+
Sodium carbonate	+
Tributoxyethyl phosphate	-
Tributyl cello phosphate	-
2 Dodecyl phenyl carbonate	+

Ether

Ether	-
Ethyl cellosolve 5%	-
Methyl cellosolve	-
Polyalkylene glycol	-
Polyethylene glycol	+
Polyethylene sulfide	-
Propylene oxide	-

Gaseous

Ammonia concentrate	-
Bromine	-
Chloracetophenon	-
Chlorine	-
Iodine	-
Isobutane	-
Methane	-
Oxygen	+
Ozone 2%	-
Propylene	+
Sulfur dioxide	-
Sulphur hexafluoride	-

Halogenated HC

Acethylene dibromo	-
Acethylene tetrabromide	-
Bromochloromethane	-
Carbon tetrachloride	-
Chlorethanol 2	-
Chlorobenzene	-
Chlorobutane	-
Chloroform	-
Dibromomethane	-
Dichloroethane	-
Dichlorohydroxybenzene	+
Dichloromethane	-
Ethyl bromoacetate	+

Ketone

Methyl ethyl ketone	-
---------------------	---

Metal & Metal Oxide

Aluminium oxide	+
Arsenic trioxide	-
Calcium oxide paste	-
Cuprous oxide	+
Mercury metallic	-

Phenol

Allyl 4methoxyphenol	-
Cresol	-
P-Phenylphenol	-
Pentachlorophenol	-
Sodium ferrycyanide	+
Sodium carbonate solvent	-
Sodium chlorate	+
Sodium nitrate 10%	-
Sodium perborate	+
Sodium phosphate	+
Sodium silicate	+
Sodium sulfide	-
Sodiumsulfite	+
Strontium bromide	+
Tin (II) chloride	+
Tin (IV) chloride	+
Titanium tetrachloride	+
Trisodium phosphate 5%	-
Zinc bromide	+
Zinc carbonate	+
Zinc chloride	-
Zinc oxide	-
Zinc sulfate	+

Salt, Organic

Aluminium acetate	+
Ammonium acetate	-
Ammonium oxalate	+
Aniline sulfate	+
Potassium acetate 30%	-
Quinine sulfate	-
Sodium acetate 30%	-
Valine bromide dl	+

CONTACT US

SABIC Global Headquarters

PO Box 5101
Riyadh 11422
Saudi Arabia
T +966 (0) 1 225 8000
F +966 (0) 1 225 9000
E info@sabic.com

Americas

SABIC
Functional Forms
2500 CityWest Boulevard
Suite 100
Houston, Texas 77042
USA
T +1 800 323 3783
F +1 888 443 2033
E spinside.sales@sabic.com

Europe

SABIC
Functional Forms
Plasticslaan 1
4612 PX
Bergen op Zoom
The Netherlands
T +31 (0)164 293684
F +31 (0)164 293272
E ff.info@sabic.com

Pacific

SABIC
Functional Forms
2550 Xiupu Road
Pudong
201319 Shanghai
China
T +86 21 3222 4500
F +86 21 6289 8998
E ff.info@sabic.com



DISCLAIMER: THE MATERIALS, PRODUCTS AND SERVICES OF SAUDI BASIC INDUSTRIES CORPORATION (SABIC) OR ITS SUBSIDIARIES OR AFFILIATES ("SELLER") ARE SOLD SUBJECT TO SELLER'S STANDARD CONDITIONS OF SALE, WHICH ARE AVAILABLE UPON REQUEST. INFORMATION AND RECOMMENDATIONS CONTAINED IN THIS DOCUMENT ARE GIVEN IN GOOD FAITH. HOWEVER, SELLER MAKES NO EXPRESS OR IMPLIED REPRESENTATION, WARRANTY OR GUARANTEE (i) THAT ANY RESULTS DESCRIBED IN THIS DOCUMENT WILL BE OBTAINED UNDER END-USE CONDITIONS, OR (ii) AS TO THE EFFECTIVENESS OR SAFETY OF ANY DESIGN OR APPLICATION INCORPORATING SELLER'S MATERIALS, PRODUCTS, SERVICES OR RECOMMENDATIONS. UNLESS OTHERWISE PROVIDED IN SELLER'S STANDARD CONDITIONS OF SALE, SELLER SHALL NOT BE RESPONSIBLE FOR ANY LOSS RESULTING FROM ANY USE OF ITS MATERIALS, PRODUCTS, SERVICES OR RECOMMENDATIONS DESCRIBED IN THIS DOCUMENT. Each user is responsible for making its own determination as to the suitability of Seller's materials, products, services or recommendations for the user's particular use through appropriate end-use and other testing and analysis. Nothing in any document or oral statement shall be deemed to alter or waive any provision of Seller's Standard Conditions of Sale or this Disclaimer, unless it is specifically agreed to in a writing signed by Seller. Statements by Seller concerning a possible use of any material, product, service or design do not, are not intended to, and should not be construed to grant any license under any patent or other intellectual property right of Seller or as a recommendation for the use of any material, product, service or design in a manner that infringes any patent or other intellectual property right.

SABIC and brands marked with ™ are trademarks of SABIC or its subsidiaries or affiliates.
© 2020 SABIC. All Rights Reserved.